## **WV Communications**



## Flight Termination Panels (FTP)

The Flight Termination Panel (FTP), also known as the RSO or MFCO panel, is the user interface to the system. It accepts command requests via buttons, acknowledging them by LEDs and providing verification information via separate LEDs, traceable to the CVR in the transmitter chain. WV has a variety of FTP



configurations available, from rack mounted units to desk top units, and from single to multiple vehicle panels, as well as units with

either fixed button nomenclatures or programmable Color LCD Display pushbuttons.

FTPs can be supplied with either toggle or pushbuttons switches. With pushbuttons, the button illuminates to show the logical state of the command and can be logically programmed in the FCP for a variety of

actions, such as momentary, push lock/push release, or interlock. If toggle switches are used, they must be Logically programmed as momentary, and will physically hold the desired state. This provides less versatility of action, but can be compatible with the rest of the system. From the FTP's perspective, the physical state of the button is sent and the logical state is received for indicatior purposes. Pushbuttons are physically momentary.



Additionally, two types of pushbutton switches are available; with the first type consisting of an LED illuminated switch with engraved nomenclature lens cover indicating the switch function, another type consisting of an color LCD programmable display switch that is programmed via the FPS.

The FTPs contain a processor board for each communication path (two or more for redundancy), the only non-redundant components are the buttons and LEDs themselves, and a supervisory CPU that monitors fault conditions. Each processor board has its own 48VDC Power Supply/DC-DC converter and rear panel power connector creating redundant power entry.



All switches are DPDT providing a total of four contacts (2 NO and 2 NC). Each processor board uses one NO and one NC contact to provide redundant switch state information. A fault is reported if the switch remains in an illegal state for any length of time. The second pole goes to the second processor board. If there are more than two processor boards, they alternate. Each

processor board contains isolation diodes to localize any fault that might occur in the board.

The LED indicators are driven by each processor board, therefore a board failure or FCP fail-over will not cause faulty indication. The LED signals are diode isolated to minimize the possibility of wrong indication from a faulty board. Each board clears all indications any time it is reset or loses communication with the FCP, to insure that it is not erroneously driving indicators. Each Processor board also incorporates a Watch Dog Timer to reset the CPU in case of software malfunction.

1125A Business Center Cr, Newbury Park, CA 91320 - (805) 376-1820 - FAX (805) 376-1840 - www.wv-comm.com